

# Cast Free Standing Bath

## Outer cast surface painting instructions



1. Un-plumb the bath and invert.
2. Mask off the feet with masking tape.
3. Key the surface to be painted by rubbing with 120 grade (or equivalent) sandpaper.
4. Ensure that any dust or debris is removed from the surface, this can be done using a soft damp cloth. Make sure the surface is dry before painting.
5. Prime with a good quality acrylic paint compatible primer and allow to dry fully.
6. To apply the finish coat, lightly key primer coat by rubbing with 180 grade (or equivalent) sandpaper. Wipe dust away before applying the finish coat.
7. Best results are achieved by using a good quality acrylic paint for the finish coat. This needs to be applied as a smooth and even coat over the primed surface.
8. Allow the finish coat to dry fully before removing any masking from the feet.
9. Once fully dry, return the bath to its upright position and re-plumb.



766 Upper Newtownards Road  
Dundonald BT16 1TQ  
United Kingdom  
T 028 9048 0465  
F 028 9048 0485  
E [info@adamsez.com](mailto:info@adamsez.com)  
[www.adamsez.com](http://www.adamsez.com)